


TENDONS INSTALLATION


CELLTEK SECTIONS SHOULD BE PLACED BEYOND THE CREST OF THE SLOPE TO PREVENT SURFACE WATER UNDERMINING THE SECTIONS.



VARIABLES


MILD STEEL
OPTIONAL GALVANIZED
(AASHTO M-218)

J-HOOK (REBAR)




INSTALLATION WITH TENDONS

- STEP 1: MAKE 2 LOOPS IN THE TENDON.
- STEP 2: PULL LOOP 1 PARTIALLY THROUGH LOOP 2.
- STEP 3: INSERT THE J-HOOK ANCHOR THROUGH LOOP 1 AND DRIVE J-HOOK INTO THE GROUND UNTIL THE TOP OF THE HOOK IS LEVEL WITH THE TOP OF THE CELLTEK SECTION.
- STEP 4: PULL BOTH ENDS OF TENDON TO CLOSE THE LOOP AND DRIVE J-HOOK UNTIL THE TOP OF IT IS FLUSH WITH GROUND SURFACE.




INSTALLATION NO TENDONS


- STEP 1: POSITION STAKE NEXT TO CELL WALL.
- STEP 2: DRIVE STAKE INTO THE GROUND UNTIL FLUSH WITH TOP OD CELL WALL.




EXPANDED




TOP VIEW




ISOMETRIC VIEW



DEAD MAN SYSTEM



HARPOON-LIKE SYSTEM



COLLAPSED

BUDLED SIZE
APPX 22" X 54"
(PACKAGED)

REVISIONS:

INSTALLATION DETAILS

CELL-TEK
synthetics

TOLL FREE 888-851-0051
WWW.CELLTEKDIRECT.COM